





























Kompatibilní ovladače

Firma	Frekvence	Model	Photo	Podporuje:
ADYX	433.920	ALIZE EM2C, ALIZE EM4C		IDEAL Multi, IDEAL
AETERNA	433.920	TX433 1,2,4 buttons		IDEAL Multi, IDEAL
ALLMATIC	306.000	ASMX2, ASMX4		IDEAL Multi
	433.920	AEMX1, AEMX2, AEMX4		IDEAL Multi, IDEAL
		EUROPE AUTO ARMY1, ARMY2, ARMY4		IDEAL Multi, IDEAL
		MX1, MX2, MX4		IDEAL Multi, IDEAL
ALLISTER	318.000	9931-318, 9931T- 318		IDEAL Multi
ALLSTAR	288.000	111025 Allister Pulsar Quickcode		IDEAL Multi
		9921T-288, 9921MT, 9921TK, 9922T-288, 9923T- 288, 9931-288, 9931T-288, 9931MT, 9931TK, 9931TK6, 8831T- 288, 8832T-288, 8833T-288, 8821T- 288, 8822T-288, 8823T-288, 8832TK		IDEAL Multi
		8833OCS-288		IDEAL Multi
	318.000	9921T-318, 9921MT, 9921TK, 9922T-318, 9923T- 318, 9931-318, 9931T-318, 9931MT, 9931TK, 9931TK6, 8831T- 318, 8832T-318, 8833T-318, 8821T- 318, 8822T-318,		IDEAL Multi

		8823T-318, 8832TK		
		110995 Allister Pulsar Quickcode		IDEAL Multi
		8830OCS-318		IDEAL Multi
ALLTRONIK	433.920	S429_1, S429_2, S429_4, S429_M	 	IDEAL Multi Rev.3, IDEAL Rev.3
		S425		IDEAL Multi Rev.3, IDEAL Rev.3
ANSONIC	433.920	SA 434-1E, SA434- 2E, SA434-3E, SA434-4E		IDEAL Multi, IDEAL
		SA 434-1MINI, SA434-2MINI, SA 434-2Midi		IDEAL Multi, IDEAL
	868.350	SA 868-1E, SA 868-2E, SA868-3E, SA868-4E		IDEAL Multi
		SA 868-1mini/M, SA 868-2mini/M (dip switch version)		IDEAL Multi
APERTO	433.920	CPS1, CPS2, CPS4		IDEAL Multi, IDEAL
APRIMATIC	305.000	TS1, TS2		IDEAL Multi
AUTELCO	286-306	TX300T		IDEAL Multi
AVIDSEN	433.920	100601 micromark MM23164		IDEAL Multi, IDEAL
		104505		IDEAL Multi, IDEAL
		100951, 100955, 100550, 100400		IDEAL Multi, IDEAL
B&D BnD	433.920	062170/4333EBD, 062171, 4333A		IDEAL Multi, IDEAL








BD		062162		IDEAL Multi, IDEAL	
		PTX4 059120 / 059116		IDEAL Multi, IDEAL	
BANDY	433.920			IDEAL Multi, IDEAL	
BELFOX	433.920	DHS433-1, DHS433-2, DHS433-4, dip switch version		IDEAL Multi, IDEAL	
		DHS 433,92 (7733), dip switch version		IDEAL Multi, IDEAL	
	868.350	DHS 868,3, dipswitch version		IDEAL Multi	
		HS 868-20		IDEAL Multi	
BENINCA'	306.000	LOT1A, LOT2A, LOT4A		IDEAL Multi	
		LOTX1A, LOTX2A, LOTX4A		IDEAL Multi	
		LO.TX2PS		IDEAL Multi	
	433.920	LOT1W, LOT2W, LOT4W		IDEAL Multi, IDEAL	
		LOT2WMS		IDEAL Multi, IDEAL	
		T2WK, T4WK		IDEAL Multi, IDEAL	
		LOTX1W, LOTX2W, LOTX4W		IDEAL Multi, IDEAL	
		TO.GO2WP, TO.GO4WP, TO.GO2WK, TO.GO4WK		IDEAL Multi, IDEAL	
	BERNER	868.300	Berner BHS140		IDEAL Multi Rev.04e
			Berner BHS130		IDEAL Multi Rev.04f







BESIDE	433.920	BEZAP		IDEAL Multi, IDEAL
		HIT		IDEAL Multi, IDEAL
BETA ELETTRONICA	315.000	BETALARM 6500		IDEAL Multi
	330.000	BETALARM 5500		IDEAL Multi
BFT	306.000	RCS		IDEAL Multi R3
	315.000	VTM1, VTM2, VTM4		IDEAL Multi
	418.000	GT01, GT02, GT04		IDEAL Multi
	433.920	TE01, TE02 (TE01, TE02)		IDEAL Multi, IDEAL
		TE04 (TE04)		IDEAL Multi, IDEAL
		MITTO 2, MITTO 4: Only if the receiver is CLONIX 1 or CLONIX 2 with DIP2 in ON position		IDEAL Multi, IDEAL
BREDA	433.920	Breda TOP432SA	Like CAME TOP432SA, blue	IDEAL Multi, IDEAL
CAME	315.000	Came T312M, T314M		IDEAL Multi
		Came TOP312, TOP314		IDEAL Multi
		Came TOP432NA, TOP434NA		IDEAL Multi
	433.920	Came T432, T434, TOP432A, TOP434A, TOP432, TOP432NA, TOP434NA,		IDEAL Multi, IDEAL









		TAM432, TAM434, TAM438		
		Came TOP432M, TOP434M		IDEAL Multi, IDEAL
		Came TAM432SA		IDEAL Multi, IDEAL
		Came TOP432SA		IDEAL Multi, IDEAL
		Came TOP432NA, TOP434NA		IDEAL Multi, IDEAL
		Came TWIN2, TWIN4		IDEAL Multi, IDEAL
		CAME TOP- 432EV, TOP- 434EV		IDEAL Multi, IDEAL
	868.350	CAME TOP862NA, Came TOP864NA		IDEAL Multi
CARDIN	300.000	S300		IDEAL Multi
	310.000	S301, S302		IDEAL Multi
	433.920	S476 TX2, S476TX4		IDEAL Multi, IDEAL
CARPER	300.000 310.000 318.000	C300, C310, C318, C318T		IDEAL Multi
	330.000			IDEAL Multi
	433.920	Genius 433 2, Genius 433 3, JA400 TM433, JA401 TM433		IDEAL Multi, IDEAL
CASIT	306.000	ERTS92B, ERTS92T		IDEAL Multi
	433.920	ERTS92B, ERTS92T		IDEAL Multi, IDEAL
		ERTS20DB, ERTS20DQ		IDEAL Multi, IDEAL
		ERTS476D, ERTS476Q		IDEAL Multi, IDEAL







		TXS1, TXS2, TXS3, TXS4, TXS6 ERTS97B, ERTS97T		IDEAL Multi, IDEAL
CEDAMATIC	305.000	Cedamatic CTX1S, CTX2S, CTX4S		IDEAL Multi
	433.920	Cedamatic AEMX1, AEMX2, AEMX4		IDEAL Multi, IDEAL
CELINSA	433.920	S10 1, S10 2, SAW1, SAW2		IDEAL Multi, IDEAL
CENTURION	433.920	CLASSIC, SMART, SMART2		IDEAL Multi, IDEAL
CHAMBERLAIN LIFTMASTER MOTORLIFT SEARS CRAFTSMAN	300.000	Chamberlain 300MC (multicode)		IDEAL Multi
	315.000	333LM		IDEAL Multi
		360LM, 362LM, 363LM		IDEAL Multi
	390.000	50CB, 53CB, 750CB, 753CB, 50LM, 53LM, 61LM, 62LM, 63LM, 139.53100, 139.53110, 139.53200, 139.53210		IDEAL Multi
		54CB, 756CB, 54LM, 64LM, 859CB		IDEAL Multi
		850CB, 853CB, 959CB, 81LM, 82LM, 83LM, 84LM, 99LM		IDEAL Multi
		33LM		IDEAL Multi
	418.000	4180, 4182, 4183		IDEAL Multi
		4185		IDEAL Multi
		787 remote keyless entry		IDEAL Multi

	433.920	4330E, 4332E, 4333E		IDEAL Multi, IDEAL
		4335E		IDEAL Multi, IDEAL
COSTEL	300.000	Minitix		IDEAL Multi
CPS	433.920	TCP3, CPS, Jolly 4		IDEAL Multi, IDEAL
		CPS1 TCP3, CPS2 TCP3, CPS4 TCP3 EM1CV, EM2CV, EM4CV		IDEAL Multi, IDEAL
DASPI	433.920	Daspi Happy2 433, Daspi Pops2		IDEAL Multi, IDEAL
		Daspi Zero2, Zero2CLO, Zero4CLO		IDEAL Multi, IDEAL
DEA	306.000	306 1, 306 2, 306 4		IDEAL Multi
		306		IDEAL Multi
	433.920	433 1, 433 2, 433 4, Gold S1, Gold S2 Dea Gold 238 S1, Dea Gold 238 S2, Dea Gold 239 S4		IDEAL Multi, IDEAL
		Genie		IDEAL Multi, IDEAL
		Punto S2		IDEAL Multi, IDEAL
		Dea MIO TD2, MIO TD4		IDEAL Multi, IDEAL
DELMA	300.000	Apollo 300, ELSAMEC Apollo 300		IDEAL Multi
		Mizard 300 1, Mizard 300 2, King		IDEAL Multi
	433.920	Mizard 433 1, Mizard 433 2		IDEAL Multi, IDEAL














		King 433 2		IDEAL Multi, IDEAL
		Style Copy 2CH (this is a code duplicator)		IDEAL Multi, IDEAL
DICKERT	433.920	Dickert MAHS433 01, MAHS433 04 Note: we can NOT guarantee that it can be duplicated, because it depends by the receiver.		IDEAL Multi, IDEAL
		Dickert S10-433A1L00, S10-433A4L00, S20-433A1L00, S20-433A4L00, S20-433A1000, S20-433A4000 Note: only RED buttons model can be duplicated!		IDEAL Multi, IDEAL
		Dickert S5-433-A2L00, S5U-433-A2L00 Note: only RED buttons model can be duplicated!		IDEAL Multi, IDEAL
	868.350	Dickert HS868-21 Note: only RED buttons model can be duplicated!		IDEAL Multi
		Dickert S5-868A2L00, S5U-868A2L00 Note: only RED buttons model can be duplicated!		IDEAL Multi

		<p>Dickert S10-868A100, S10-868A400, S20-868A1L00, S20-868A4L00, S20-868A1000, S20-868A4000</p> <p>Note: only RED buttons model can be duplicated!</p>		IDEAL Multi
		<p>Dickert S5-868A2L01, S10-868A1L01, S10-868-A4L06, green buttons</p>		IDEAL Multi
DIGICODE	300.000 310.000	DC5010, DC5012, DC5030, DC5032, DC5040, DC5042, DC5060, DC5062, DC5070, DC5072		IDEAL Multi
DITEC	433.920	GOL4C		IDEAL Multi, IDEAL
		<p>GOL4</p> <p>Note: These transmitters are rolling code and cannot be duplicated, but if you have a GOL4C device, you can duplicate it</p> <p>on Four or Multi, and it works with all the DITEC receivers.</p>		IDEAL Multi, IDEAL
		<p>BIX LS2, BIX LP2, BIX LG4</p> <p>Note: These transmitters are rolling code and</p>		IDEAL Multi, IDEAL









		<p>cannot be duplicated, but if you have a GOL4C device, you can duplicate it</p> <p>on Four or Multi, and it works with all the DITEC receivers.</p>		
DOITRAND FDOITRAND	433.920	MPSTF2E JAUNE, MPSTF4E, HYPERPHONE MPSTF2E_GRISE		IDEAL Multi, IDEAL
		TS2DE, TS4DE		IDEAL Multi, IDEAL
DOORHAN	433.920			IDEAL Multi, IDEAL
DOORMATIC	433.920	SAW		IDEAL Multi, IDEAL
DUCATI ALLDUCKS	433.920	TSAW1, TSAW2, TSAW3, TSAW4, 124 ELBER TSAW1, TSAW2, TSAW3, TSAW4 RONDY TSAW1, RONDY TSAW2, RONDY TSAW3		IDEAL Multi, IDEAL
		TPR10-A, TPR20-A RONDY TPR10_A, RONDY TPR20_A		IDEAL Multi, IDEAL
		TE2		IDEAL Multi, IDEAL
		HC6203, 6203: only blue with transparent buttons, and transparent with transparent buttons		IDEAL Multi, IDEAL
DÜWI	433.920	Several models, handsender used for		IDEAL Multi, IDEAL




DUWI REV Ritter		radio sockets		
ECP	292.000	FIX 292 MHz F105611		IDEAL Multi
		KEY 292 MHz F106038		IDEAL Multi
ELBE	433.920	501, 502, 504		IDEAL Multi, IDEAL
		502a, 504a		IDEAL Multi, IDEAL
		502, 504		IDEAL Multi, IDEAL
ELCA	300.000	Aster 1100, Aster 1101		IDEAL Multi
	433.920	IRIS, IRIS 9CH. Model 433D only! Both colors red and blue		IDEAL Multi, IDEAL
		ASTER2		IDEAL Multi, IDEAL
		Aster 1000, Aster1001. Model 433D only! Colors: black, blue, light grey		IDEAL Multi, IDEAL
		GEMINI 9CH		IDEAL Multi, IDEAL
	VIRGO		IDEAL Multi, IDEAL	
ELDAT MFZ	433.920	Eldat Basewave RT20-4103M-01, RT20-4104M-01, RT35-4104M-01, RT21-4101M-01, RT21-4102M-01, MFZ 400033		IDEAL Multi, IDEAL
		Eldat Basewave RT28-4101M-01,		IDEAL Multi, IDEAL















		RT27-4101M-01, RT26-4101M-02, RT21-4125M-01, RT21-4139M-01, RT21-4139M-02, RT31-4139M-01, RT31-4139M-02, RTC02-4104M-01		
	868.300	Eldat Basewave RT20-5004M-01, RT20-5003M-01, RT35-5004M-01, RT21-5001M-01, RT21-5002M-01		IDEAL Multi
		Eldat Basewave RT28-5001M-01, RT27-5001M-01, RT26-5001M-02, RT21-5025M-01, RT21-5039M-01, RT21-5039M-02, RT31-5039M-01, RT31-5039M-02, RTC02-5004M-01		IDEAL Multi
ELEK	300.000	KTM194B		IDEAL Multi
		KTR4		IDEAL Multi
ELV CONRAD	868.350	FS20 S4, FS20 S8, FS20 S8-2, FS20 S16, FS20S16R, FS20 S20-2, FS20 S20-3		IDEAL Multi Rev.4
ELVOX	433.920	Elvox ET		IDEAL Multi, IDEAL
		Elvox ET03, ET04		IDEAL Multi, IDEAL
	868.350	Elvox ET08		IDEAL Multi
EMFA	287.000	ET1, ET2, ET3		IDEAL Multi
	308.000	ES_1, ES_2		IDEAL Multi
ERONE	433.920	SETDS39433E2, SETDS39433E4		IDEAL Multi, IDEAL

ERREKA	289.000	Erreka E20, Erreka E22		IDEAL Multi
	433.920	Erreka Luna, Erreka SMAT 1, RESON 1, RESON 2, RESON 3		IDEAL Multi, IDEAL
EUROPE AUTOMATISMES	306.000	ASMY1, ASMY2, ASMY4		IDEAL Multi
	433.920	ARMY1, ARMY2, ARMY4		IDEAL Multi, IDEAL
		S1, S2, S3		IDEAL Multi, IDEAL
FAAC	300.000	TM300S, TM300S05 H, Faac TM1 300, TM2 300, TM3 300		IDEAL Multi
	315.000	T1, T2, T3, Faac TM1 315, TM2 315, TM3 315		IDEAL Multi
	330.000	TM1, TM2, TM3, Faac TM1 330, TM2 330, TM3 330		IDEAL Multi
	418.000	TM1 418 DS, TM2 418 DS, TM3 418 DS		IDEAL Multi
		TM 418SL, TM1 418SL, TM2 418SL, TM3 418SL		IDEAL Multi
	433.920	TM1 433 DS, TM2 433 DS, TM3 433 DS, TM1 433DS DPH, TM2 433DS DPH, TM3 433DS DPH		IDEAL Multi, IDEAL
		TML2 433 SLR, TML4 433 SLR, TML2-433-SLR, TML4-433-SLR, TML2 433 ESL, TML4 433 ESL		IDEAL Multi, IDEAL
		TML2 433 SLP, TML4 433 SLP,		IDEAL Multi, IDEAL

		TML2-433-SLP, TML4-433-SLP		
	868.350	TM1 868 DS, TM2 868 DS, TM3 868 DS TM1 868DS DPH, TM2 868DS DPH, TM3 868DS DPH		IDEAL Multi
FADINI BPT	315.000	ASTRO75-1, ASTRO75-2, ASTRO75-4		IDEAL Multi
	433.920	433 2M, Astro43_2m		IDEAL Multi, IDEAL
		Astro433-2, Astro433-4, Astro43-2, Astro43- 4		IDEAL Multi, IDEAL
FERPORT	433.920	Tac1, Tac2, Tac4, Tac1k, Tac2k, Tac4k, Tac2kr		IDEAL Multi, IDEAL
FORSA	287.000	Forsa Trieme		IDEAL Multi
FUNKMODUL ELSECO	433.920	T433A2K1, T433A2K2		IDEAL Multi, IDEAL
		T433A2K4, T433A2K4n		IDEAL Multi, IDEAL
GIBIDI	306.000	TS2M		IDEAL Multi
	433.920	Open TMB 433, OPEN TMQ 433, OPEN OUT 2, OPEN OUT 4		IDEAL Multi, IDEAL
GOBBATO	306.000	T306		IDEAL Multi
GRIFFON	403.55	Griffon 404 MHz dip switch remotes and duplicating remotes		IDEAL Multi
	433.92	Griffon 433 MHz dip switch remotes and duplicating remotes		IDEAL Multi, IDEAL

















GTO	318.000	GTO Mighty Mule 1/2 buttons, RB741, RB742		IDEAL Multi
		GTO Mighty Mule 3 buttons, RB743		IDEAL Multi
GULLIVER	306.000	MDRQ 306		IDEAL Multi
	433.920	MDW 2E		IDEAL Multi, IDEAL
HAUSS	433.920	Pocket 3750-1, Pocket3750-2, Pocket 3750-4		IDEAL Multi, IDEAL
HEDDOF	318.000	P219-1, P219-2		IDEAL Multi
		P220-1, P220-2, P220-3		IDEAL Multi
HORMANN HOERMANN	433.920	HSM2, HSM4, yellow buttons Please note that, in Netherlands, Hoermann sell this kind of remote control which transmit a rolling code: in this case it cannot be duplicated!		IDEAL Multi, IDEAL
	868.300	HS1, HS2, HS4, blue buttons		IDEAL Multi
		HSD2		IDEAL Multi
		HSE2, HSE4, blue buttons		IDEAL Multi

		HSM2, HSM4, blue buttons		IDEAL Multi
		HSP4, blue buttons		IDEAL Multi
		HSS2, HSS4, blue buttons		IDEAL Multi
		HSZ1-868, HSZ2-868		IDEAL Multi
HRC	433.920			IDEAL Multi, IDEAL
JAY	433.920	UBEI x1 SL1		IDEAL Multi, IDEAL
		UBET 11, UBET 21, UBET 31, UBET 41, UBET 61Ã,		IDEAL Multi, IDEAL
JCM	290.000	EC1, EC2, EC3, ET1, ET2, ET3		IDEAL Multi
KEYAUTOMATION	433.920	900TXB-42, 900TXB-42N, 900TXP-42, 900TXP-42N		IDEAL Multi, IDEAL
		900TXB-44, 900TXG-44		IDEAL Multi, IDEAL
		900SUB-44, 900SUB-44N, 900SUB-44W, 900SUB-44WN		IDEAL Multi, IDEAL
		900TXK-42, 900TXW-42, 900TXK-44, 900TXW-44		IDEAL Multi, IDEAL
KING	433.920	Note: receiver should be setup withrolling code feature disabled		IDEAL Multi, IDEAL
LABEL IUPPITER	306.000	MDR, IUPPITER 306		IDEAL Multi

















	433.920	RJW/1E, RJW/2E, RJW/4E, RJW/12E		IDEAL Multi, IDEAL
		MDW/1E, MDW/2E		IDEAL Multi, IDEAL
LEB	306.000	TSA4		IDEAL Multi
	433.920	TMW		IDEAL Multi, IDEAL
		TSAW2N, TSAW4N		IDEAL Multi, IDEAL
		TCP3Ã, (this is a code duplicator)		IDEAL Multi, IDEAL
		TRK4 Note: receiver should be configured to disable rolling check.		IDEAL Multi, IDEAL
		TPW4		IDEAL Multi, IDEAL
	868.300	TPK4		IDEAL Multi
LINCE	302.000	LE TX1, LE TX2		IDEAL Multi
	433.920	LR 2035		IDEAL Multi, IDEAL
LINEAR	300.000 310.000	MULTI-CODE 308911, 308913, 1089		IDEAL Multi
		MULTI-CODE 412001, 414001, 109410, 109710		IDEAL Multi
		MULTICODE 306010, 307010, 108210		IDEAL Multi
		MULTI-CODE 308301, 308302		IDEAL Multi
		MULTI-CODE 105015		IDEAL Multi

	310.000	Delta3 Moore-o-Matic: DT, DT2, DT2A, DT22A, DTC, DTD		IDEAL Multi
		Delta 3 Moore-o-Matic: DT3, DT4		IDEAL Multi
		Delta 3 Moore-o-Matic: Mini-T LB "LadyBug"		IDEAL Multi
	312.000	Delta3 DTK (canada)		IDEAL Multi
MA SYSTEM	433.920	MA TX1, MA TX2, MA TX3		IDEAL Multi, IDEAL
MARANTEC	418.000	D212, D222, D232		IDEAL Multi
	433.920	D101		IDEAL Multi, IDEAL
		D12		IDEAL Multi, IDEAL
		D212, D222, D232		IDEAL Multi, IDEAL
		Digital 302, D302		IDEAL Multi Rev.4, IDEAL Rev.4
		Digital 304, D304		IDEAL Multi Rev.4, IDEAL Rev.4
	868.300	Digital 302, D302		IDEAL Multi Rev.4 Rev.4
		Digital 304, D304		IDEAL Multi Rev.4 Rev.4
MCZ	433.920	Aster		IDEAL Multi, IDEAL
MEIÄfÅ ,NER MEISSNER	433.920	LW433-1, LW433-2, LW433-4		IDEAL Multi, IDEAL
		Pocket 3750 1, 2, 4		IDEAL Multi, IDEAL
MKTECHNO MK-TECHNO	306.000	MK-TECHNO TX1 and MKTECHNO TX2 with RED		IDEAL Multi

		LED		
MONSEIGNEUR	433.920	ARC2, ARC4		IDEAL Multi, IDEAL
		TDR 400 3845, TDR 400 3846, TDR 400 3847 T1SAW433, T2SAW433, T4SAW433		IDEAL Multi, IDEAL
MOTORLINE STATEUROP	433.920	MX1, MX2, MX3, MX4, MX6 MX11, MX12, MX13		IDEAL Multi, IDEAL
MOTOSTAR	433.920	CLIKSTAR2, CLICKSTAR4 CLICK-4M, CLICKSTAR RE 532, CLICKSTAR RE 534		IDEAL Multi, IDEAL
NICE	306.000	EASY S1, S2, S4		IDEAL Multi
	433.920	FLO1, FLO2, FLO4 VERY VE		IDEAL Multi, IDEAL IDEAL Multi, IDEAL
NOLOGO	306.000			IDEAL Multi
	433.920	ECO DIP		IDEAL Multi, IDEAL
NOVOTECNICA	306.000	BIT N1, BIT N2		IDEAL Multi
		BIT NT1, BIT NT2, BIT NT4		IDEAL Multi
OG	433.920	OG62, OG64		IDEAL Multi, IDEAL
O&O OeO, OandO,OetO	306.000	OeO TX2, TX4 (green buttons)		IDEAL Multi

		OeO TX4-E, TX2-E (red buttons)		IDEAL Multi, IDEAL
	433.920	OeO T-COM DS 4-2, O&O T-COM DS 4-4		IDEAL Multi, IDEAL
OPENOUT	306.000	TS2M		IDEAL Multi
	433.920	TMQ 433 2, TMQ 433 4		IDEAL Multi, IDEAL
PIAZZETTA	433.920	4 buttons for wood/pellet heater		IDEAL Multi, IDEAL
PORTAMATIC	433.920	MPH01, MPH02		IDEAL Multi, IDEAL
POWERFIX Profi (Lidl)	433.920	RCB-A 3600R		IDEAL Multi, IDEAL
PRASTEL	306.000	NCSMT1, NCSMT2P, NCSMT4P		IDEAL Multi
		KMFT2P, KMFT4P, KMFT2P93, KMFT4P93		IDEAL Multi
	433.920	MPSTF2E, MPSTF4E		IDEAL Multi, IDEAL
PROEM	433.920	ER2C4ACM, ER4C4ACM		IDEAL Multi, IDEAL
PROGET	433.920	ETY_433N2, ETY 433N4		IDEAL Multi, IDEAL
		EMI433-N2		IDEAL Multi, IDEAL
PROTECO	433.920	TX433		IDEAL Multi, IDEAL
		EUROMATIC		IDEAL Multi, IDEAL
		HIT		IDEAL Multi, IDEAL

PUJOL	288.000	JCM TRINARIO 1, TRINARIO 2, TRINARIO 3		IDEAL Multi
	288.000	TT1, TT2, TRINARIO 1, TRINARIO 2		IDEAL Multi
PULSAR	318.000	9931-318, 9931T- 318		IDEAL Multi
QUASAR	287.000	Tx SA4, Serie Argento, SA		IDEAL Multi
	287.000	TXSA2T		IDEAL Multi
	306.000	300 2, 300 4		IDEAL Multi
	433.920	433 TANGO SLIM BLEU		IDEAL Multi, IDEAL
QUICK	433.92	Model: 302		IDEAL Multi
RADIODIGIT	291.000	TBM, TCM		IDEAL Multi
ROGER	433.920	R80/TX12, R80/TX14, R80/TX12R, R80/TX14R		IDEAL Multi, IDEAL
		H80/TX22		
		G80/TX32, G80/TX34, G80/TX32R, G80/TX34R		
SEA	433.920			IDEAL Multi, IDEAL
		SMART433_TX2_ DIP, SMART433_TX3_ DIP SMART433_TX2_ COPY,SMART433_ TX3_COPY Smart2 Dip Switch, Smart3 Dip Switch		IDEAL Multi, IDEAL
	868.350	231103, SEA868_4		IDEAL Multi









		231103, Head2 Dip Switch		IDEAL Multi
		SMART868-TX2-DIP, SMART868-TX3-DIP Smart2 Dip Switch, Smart3 Dip Switch		IDEAL Multi
SEAV	306/330	TX1, TX2, TX3, TX4, TX1/330 TX2/330, TX3/330, TX4/330		IDEAL Multi
	433.920	TXS1, TXS2, TXS3, TXS4		IDEAL Multi, IDEAL
		Behappy S1, Behappy S2, Behappy S3		IDEAL Multi, IDEAL
		Be Easy TX, Be Easy Murale2		IDEAL Multi, IDEAL
		BeSmart S2, BeSmart S4		IDEAL Multi, IDEAL
		BeFree S1		IDEAL Multi, IDEAL
	868.300	BeSmart H2, BeSmart H4		IDEAL Multi
		BeFree H1		IDEAL Multi
SECURVERA	433.920	SV R2C		IDEAL Multi, IDEAL
		SV R2C		IDEAL Multi, IDEAL
		SV R4C		IDEAL Multi, IDEAL
		SV R6C		IDEAL Multi, IDEAL
SENDER	433.920			IDEAL Multi, IDEAL
SENTRY MARTIN ELECTRONICS	403.550	SENTRY binary, SENTRY trinary		IDEAL Multi
	433.920	SENTRY binary		IDEAL Multi, IDEAL





SERAI	310.000	OG/32		IDEAL Multi
	433.920	OG/52, OG/54, OG/82, OG/84		IDEAL Multi, IDEAL
		OG/28, OG/48, OG/62, OG/64		IDEAL Multi, IDEAL
		OG/02, OG/04		IDEAL Multi, IDEAL
SICE	433.920	TX4 CLACK Bigfoot		IDEAL Multi, IDEAL
SILVELOX - INTRA	306.000	Green case with black buttons		IDEAL Multi
	433.920	Silvelox Intra HSM4		IDEAL Multi, IDEAL
SIMBA	433.920	Simba RC1, Simba RC4		IDEAL Multi, IDEAL
SIMINOR	433.920	ER2C4ACM, ER4C4ACM, ER2C4ACS, ER4C4ACS		IDEAL Multi, IDEAL
SKYLINK	300.000 310.000	MultiLink SD300M, Skylink 100, LD310M, SD310M		IDEAL Multi
	318.000	Skylink Mtilink PD-318M		IDEAL Multi
	390.000	Multilink CB- 390M, CD-390M (versions compatible with Chamberlain)		IDEAL Multi
SMD	433.920	LW433-1, LW433- 2, LW433-4 : AM models only		IDEAL Multi, IDEAL
SOMFY	433.920	LEB TMW		IDEAL Multi, IDEAL
SPARKRITE	?	SRA2-2		IDEAL Multi

STAGNOLI	433.920	ZEUS AZTR		IDEAL Multi, IDEAL
	868.350	ZEUS AZTR		IDEAL Multi
STANLEY	310.000	24286		IDEAL Multi
		1082		IDEAL Multi
		1050		IDEAL Multi
		1094		IDEAL Multi
		1097		IDEAL Multi
STARTEC	433.920	TXQ2		IDEAL Multi, IDEAL
STINGER	300.000 310.000 318.000 390.000	300MCD21V, 300MCD22V 310MCD21V, 310LID21V, 310LID22V 318ALD31V 390LMD21V, 390LMPB1V	 diff. colors	IDEAL Multi
TAU	315.000	250 TXA2, 250 TXA4		IDEAL Multi
	433.920	250 SLIM, 250K- SLIM, 250K- SLIMC		IDEAL Multi, IDEAL
		250TXD2, 250TXD4		IDEAL Multi, IDEAL
		250BUG2, 250BUG4		IDEAL Multi, IDEAL
		250T-4, 250T-4C		IDEAL Multi, IDEAL
TEC KEY	300.000	MK1010		IDEAL Multi

TECNOMATIC	433.920	TQ433		IDEAL Multi, IDEAL
TECSEN BERNER GFA Elektromaten	433.920	SKX1MD, SKX2MD, SKX3MD, SKX4MD		IDEAL Multi, IDEAL
		SKX1KD, SKX2KD, SKX4KD, SKX6KD		IDEAL Multi, IDEAL
		SKX1DL, SKX2DL, SKX3DL, SKX4DL		IDEAL Multi, IDEAL
		SKX1LC, SKX2LC, SKX3LC, SKX4LC		IDEAL Multi, IDEAL
		SKX1SL, SKX2SL, SKX3SL, SKX4SL		IDEAL Multi, IDEAL
		SKJ		IDEAL Multi, IDEAL
		SKX1WD, SKX2WD, SKX4WD, SKX11WD, SKX22WD, SKX44WD		IDEAL Multi, IDEAL
TELCOMA	306.000	RCS TP2		IDEAL Multi Rev.4
		RCST2, RCST4		IDEAL Multi Rev.4
	433.920	Telcoma EDGE 2, Telcoma EDGE 4		IDEAL Multi, IDEAL
		TANGO 2 SW, TANGO4 SW		IDEAL Multi, IDEAL
		TANGO BLUE 2, TANGO 4 BLUE, TANGO BLEU 2, TANGO BLEU 4		IDEAL Multi, IDEAL
		TANGO 2 N, TANGO 4 N		IDEAL Multi, IDEAL

		TANGO 2 SLIM, TANGO 4 SLIM		IDEAL Multi, IDEAL
		Telcoma Noire2, Noire4 Note: Rolling- code jumper should be removed from the receiver!		IDEAL Multi, IDEAL
		TANGO WIN3		IDEAL Multi, IDEAL
		TANGO2, TANGO4		IDEAL Multi, IDEAL
TELEMATIC	300.000	TL1, TL2		IDEAL Multi
TKC	433.920	TSAW433		IDEAL Multi, IDEAL
TONKARR	287.000	TK2		IDEAL Multi
TORAG	433.920	S429 1, S429 2, S429 4		IDEAL Multi, IDEAL
TORMATIC DORMA	433.920	HS, Dorma HS43 1E, HS43 2E, HS43 3E, HS43 4E		IDEAL Multi, IDEAL
		MAHS, Siebau, Novoferm, Dorma		IDEAL Multi, IDEAL
		MHS, MHS43-1		IDEAL Multi, IDEAL
TREMA	433.920	TO93TV1, TO93TV2, TO93TV4		IDEAL Multi, IDEAL
TUBAUTO	433.920	DIGITAL 101 433		IDEAL Multi, IDEAL
V2	306.000	TRR1_306		IDEAL Multi
	318.000	TPS1K		IDEAL Multi

	433.920	<p>PHOENIX series: Phoenix2, Phoenix2P, Phoenix4, Phoenix4P, TXC2 Contr.47, TXC4 Contr.47, Handy2 Contr.47, Handy4 Contr.47, TRC4 Contr.47, TSC4 Contr.47 .</p> <p>Note:the receiver should be programmed with the rolling code feature disabled. When the code is learned, LED will blink for 6 times to highlight that the code is rolling.</p>		IDEAL Multi, IDEAL
		TCP3		IDEAL Multi, IDEAL
		TCP3, ARC3		IDEAL Multi, IDEAL
		TCP3		IDEAL Multi, IDEAL
		TPR		IDEAL Multi, IDEAL
		T1SAW/433, T2SAW/433, T4SAW/433		IDEAL Multi, IDEAL
		TRR1, TRR2, TRR4		IDEAL Multi, IDEAL
		PMR2, PMR4		IDEAL Multi, IDEAL

	868.300	<p>PHOENIX series: Phoenix2-868, Phoenix2P-868, Phoenix4-868, Phoenix4P-868.</p> <p>Note:the receiver should be programmed with the rolling code feature disabled. When the code is learned, LED will blink for 6 times to highlight that the code is rolling.</p>		IDEAL Multi
VISONIC	315.000	WT100, WT100A, WT101, WT101A, WT102, WT104, WT-201, WT-201A, WT-201WP, WT-201AWP		IDEAL Multi
	418.000	WT-100, WT-100A, WT-101, WT-101A, WT-102, WT-104, WT-201, WT-201A, WT-201WP, WT-201AWP		IDEAL Multi
	433.920	WT 100, WT 100A, WT 101, WT 101A, WT 102, WT 104, WT 201, WT 201A, WT 201WP, WT 201AWP		IDEAL Multi, IDEAL
VSEG	433.920	CR SLIM		IDEAL Multi, IDEAL
VISA ELECTRONICS	306.000	VISA VRK 4021A		IDEAL Multi
	433.920	Visa Beet 1, Visa Skippy		IDEAL Multi
WAINE-DALTON	433.920	S429-1, S429-2, S429-4, S429-mini		IDEAL Multi, IDEAL

		S425		IDEAL Multi, IDEAL
WECLA CDS	433.920	433, 433_2		IDEAL Multi, IDEAL
ZULLAN	315.000	250TXA1H, 250TXA2H, 250TXA4H		IDEAL Multi
OEM	315.000			IDEAL Multi